
Douglas® Batting Tunnel Frame Installation Instructions





HARDWARE & NET INSTALLATION

- The (3) long cables should be cut 5' longer than the post spacing to allow for making loops.
- The Center Support Cross Cable should be cut 5' longer than the width between the middle posts.
- 3. Install the hardware as shown in the main layout diagram and Figures 2 & 3.
- 4. Unroll the net and lay on the ground inside the frame, locate the top border ropes.
- 5. Starting at one corner attach the top ropes of the net to the cables with carabiner clips, spaced every 3' per Figure 4.
- After net is attached to the cables and pulled to full length, attach to Center Support Cross Cable.

